



Contour Roam2 Rotating Lens Replacement

This guide will show you how to replace the rotating lens on your Contour Roam2 if it has been scratched or damaged.

Written By: Matthew Kofsky



INTRODUCTION

This guide will give you step-by-step instructions on how to replace the rotating lens cover on your Contour Roam2. Follow this guide if the lens been scratched or damaged.

TOOLS:

- [Phillips #000 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Rotating Lens



- Using the phillips head screwdriver (PH000) locate and remove the 4.45mm (.175in) screw by the 180 degree graphic on the metal ring.

 The screws in the camera are very small and can strip very easily. Apply consistent pressure when removing screws.

Step 2



- Rotate the metal ring counterclockwise until completely removed.

Step 3



- Use a spudger to pry up the black rubber ring around the lens cover.

⚠ The black rubber ring is very thin and can easily tear. Use caution when removing.

Step 4



- Remove and replace the lens cover.

To reassemble your device, follow these instructions in reverse order.