



Corsair Void Pro RGB Head Strap Padding Replacement

This guide shows how to replace the padding on the head strap on your Corsair Void Pro RGB.

Written By: Gianna Nobili



INTRODUCTION

After prolonged use, the head strap can lose its cushioning or become worn out. Replacing the padding does not involve dismantling the headphones so it does not require any mechanical experience or complex tools.

TOOLS:

- iFixit Tech Knife (1)

PARTS:

- Head Strap Cushion (1)

Step 1 — Head Strap Padding



- Carefully pull one end of the head strap up until it is loose.
- Pull the head strap back until the whole piece peels back.

i For ease, you may also remove the head strap using the iFixit tech knife.

To reassemble your device, follow these instructions in reverse order.