



# Cr-48 Chromebook Battery Replacement

Replace the battery.

Written By: Robert McLaughlin



## INTRODUCTION

Use this guide to replace the battery in your CR-48.

## Step 1 — Remove the Battery



- Slide the switch on the bottom of the laptop until the battery pops out.
- Once the battery pops out, you can remove it.

To reassemble your device, follow these instructions in reverse order.