



Craftsman 3/8 Inch Drill Variable Speed Reversible Teardown

This guide will show you how to properly take the case off of the Craftsman 3/8 Inch Drill Variable Speed Reversible.

Written By: Antioch High School



This document was generated on 2019-09-17 04:00:23 PM (MST).

INTRODUCTION

Hello, today I am here to show you how to take the case off of the Craftsman 3/8 Inch Drill.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Craftsman 3/8 in. Drill



- First get you #1 Phillips screwdriver.
- Now you unscrew all of the screws that are circled in the pictures. **MAKE SURE YOU DO NOT STRIP THE SCREWS!**

Step 2



- Once you have unscrewed all of the screws you now pull the metal head off. After you have pulled the metal head off then you pull the other half of the drill case off.

