



Cuisinart Mini-Prep DLC-2A Case Disassembly

How to replace the back panel of the Cuisinart Mini-Prep Plus

Written By: Brendan Paxton




INTRODUCTION

This guide will help you remove the back panel of the device to look inside the device.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Cuisinart Mini-Prep DLC-2A Case Disassembly



- Remove the back panel using a Phillips #1 Screwdriver on the four screws that hold it in place.

To reassemble your device, follow these instructions in reverse order.