



DJI Mavic Pro Battery Replacement

How to replace the battery for your DJI Mavic Pro M1P.

Written By: Nicole Lai



INTRODUCTION

If your drone is not turning on or the battery is dying, follow this guide to remove and replace the aircraft's battery.

Step 1 — Battery



- Grab both sides of the battery.
- Pinch the releasing buttons on both sides of the battery.
- Lift the battery up and out.

To reassemble your device, follow these instructions in reverse order.