



DJI Phantom 3 Advanced Battery Replacement

Remove your battery to begin part replacement or replace a dead battery in order to continue flying.

Written By: Quinn Tirpak



INTRODUCTION

This guide will outline the steps required to remove the battery from the DJI Phantom 3 Advanced. This is the first step for any other repair process, and can also be used to replace your battery with a fully charged one.



PARTS:

- DJI Phantom 3 Standard/Pro/Advanced Intelligent Flight Battery (1)

Step 1 — Battery



- With the battery facing you, locate the two tabs on the top and bottom of the battery as shown.

⚠ Remember to disarm and power down your quadcopter before beginning any disassembly.

Step 2



- Press the two tabs with your finger and thumb, and gently slide the battery towards you, out of the quadcopter frame.
- With your other hand, be sure to hold the quadcopter steady to ensure that it stays still.

To reassemble your device, follow these instructions in reverse order.