



DJI Spark Battery Replacement

Replace the battery of your DJI Spark if it is dead or it has stopped functioning.

Written By: Uzochi Anyanwu



INTRODUCTION

Use this guide when you need to replace the battery of your DJI Spark (model CP.PT.000903) due to any defects it may have gotten over time. The battery powers the operation of the drone and it is unable to operate without it. A faulty or inoperable battery will be unable to fully power the drone or may not be able to power the drone at all. This guide is also a useful tool when you need to access other parts of the drone, just for safety measures.

Step 1 — Battery



- Flip the drone over.
- Grip the left and right sides of the battery.
- Slide firmly forward until it pops out.

To reassemble your device, follow these instructions in reverse order.