



# DeWalt DWE305 Blade Replacement

This guide will provide step-by-step instructions for how to access and replace the blade piece for the DeWalt DWE305 reciprocating saw.

Written By: Morgan Dudley



## INTRODUCTION

Just like any power tool that uses a blade, the DeWalt Reciprocating saw blade becomes dull with use over time. To use your device as efficiently as possible the blade should be replaced as needed to make sure you get the job done fast and efficiently. For this process gloves are recommended for an extra layer of protection in the event that your hand slips while replacing the blade.

Note: Our device did not come with a blade attached, so the following guide will walk you through the steps of replacing the blade without any images of the blade itself.

## Step 1 — Blade



- Make sure that the device is unplugged from the power source and move device to well lit area. By doing this step you will reduce the likelihood of injury caused by the blade.

## Step 2



- While holding the blade in one hand use the other hand to lift the yellow latch located on the shoe of the device. Once the lever is lifted, slide the blade out of the device.

To reassemble your device, follow these instructions in reverse order.

