



Dell Alienware M11x R3 lower case Replacement

Replace the lower case of the Dell Alienware M11x R3.

Written By: Richard Maurice




INTRODUCTION

Use this guide to replace the lower case of the Dell Alienware M11x R3 or remove it for other repairs.

TOOLS:

- Mako Driver Kit - 64 Precision Bits (1)

Step 1 — Lower Case



- Loosen the 8 retaining screws on the base of the computer.
- *(i)* The screws have retaining washers to hold them in place, so they won't actually separate from the base plate.
- Remove the bottom cover from the laptop.

To reassemble your device, follow these instructions in reverse order.