



# Dell Inspiron 15z-5523 Battery Replacement

We will disassemble the computer to replace the battery pack within the Dell Inspiron 15z-5523.

Written By: Christian Chavez




## INTRODUCTION

Follow this guide if you want to replace the battery of your Dell Inspiron 15z-5523.

### TOOLS:



- Pro Tech Toolkit (1)

## Step 1 — Battery



- Remove all rubber stoppers and screw from the back of the laptop

## Step 2





- Detach keyboard from the laptop
- Unscrew 4 screws on the metal frame (yellow circles)
- Disconnect the 4 data connections (teal arrows)

## Step 3



- Remove top computer frame

## Step 4



- Remove the 5 screws that holding the old battery
- Gently lift up battery and pull it out

To reassemble your device, follow these instructions in reverse order.