




Dell Inspiron 11 3179 Display Hinges Replacement

Written By: Terrence15




INTRODUCTION

In this guide, we will show you how to remove and replace the Display Hinges.

TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)


Step 1 — Peeling the Tapes



⚠️ WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#).


- Peel the tapes and remove the antenna cables from the routing guide on the hinge cover.

Step 2 — Remove the Screws




- Remove the screws that secure the display hinges to the display back-cover and antenna assembly.

Step 3 — Lifting the Display Hinges




- Lift the display hinges off the display back-cover and antenna assembly.

Step 4 — Aligning the Screw Holes




- Align the screw holes on the **NEW** display hinges with the screw holes on the display back-cover and antenna assembly.

Step 5 — Replace the Screws



- Replace the screws that secure the display hinges to the display back-cover and antenna assembly.

Step 6 — Routing the Antenna Cables



- Route the antenna cables through the routing guide on the hinge cover and secure it in place.

To reassemble your device, follow these instructions in reverse order.