



Dell Inspiron 11-3147 Fixing no power on issues

Dell Inspiron 3147 issues with not wanting to power on, no visual, no fan or hard drive sounds.

Written By: alarson118



INTRODUCTION

This guide provides the steps needed to put the Power Circuit into the correct state and allowing laptop to power on.

TOOLS:

- Phillips #0 Screwdriver (1)
- Phillips #1 Screwdriver (1)
- Heavy-Duty Spudger (1)

Step 1 — Remove Back Cover



- (9) 0.7mm Screws holding back cover in place
- Small plastic tabs holding cover in place.


Step 2 — Battery Removal



- (3) 0.4mm screws holding battery in place
- Once screws are removed battery can be safely removed.

This document was generated on 2019-09-23 06:00:55 PM (MST).

Step 3 — CMOS Battery Removal



- Lift battery up and out with plastic spudger.

To reassemble your device, follow these instructions in reverse order.