




Dell Inspiron 1100 Hard Drive Replacement

Dell Inspiron 1100 Hard Drive Replacement

Written By: Devyn Johnson




INTRODUCTION

This guide will show you how to remove and replace the hard drive for your Dell Inspiron 1100 laptop.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)

Step 1 — Remove Screws



- Turn the computer over, and remove the two M2.5 x 5-mm hard drive screws.

 **CAUTION:** If you remove the hard drive from the computer when the drive is hot, do not touch the metal housing of the hard drive.

Step 2 — Remove old Hard Drive



- Slide the Hard Drive out of the computer.

Step 3 — Insert New Hard Drive into the Computer



- Insert the drive into the bay, and push the hard drive until it is fully seated in the bay.

Step 4 — Tighten screws back into Hard Drive



- Replace and tighten the two M2.5 x 5-mm screws.

To reassemble your device, follow these instructions in reverse order.