




Dell Inspiron 13-7347 Hard Drive Replacement

Replacement of the Hard Drive for the Dell Inspiron 17-7347 laptop.

Written By: Kyle Smith



INTRODUCTION

This guide is to help with the removal and replacement of the Hard Drive from the Dell Inspiron 17-7347 laptop. The Hard Drive is important because it is used by the computer for storage and retrieval of data.

TOOLS:


- Mako Driver Kit - 64 Precision Bits (1)
- Suction Handle (1)

Step 1 — Battery




- Flip the device over, so that the back is facing up.
- Remove the ten, 7 mm, Phillips #1 screws on the back of your Dell Inspiron 13-7347.
- Use the suction cup to lift off the back case.

Step 2



- Remove the three 4 mm JIS #00 screws that secure the battery to the device.

Step 3



- Unplug the flat connector that is connected to the battery.



Step 4



- Lift the battery steadily from the device.

- ⓘ Tilt the battery upward while removing.

Step 5 — Hard Drive



- Using a Phillips #0 screwdriver, remove the two 3.0 mm hard drive screws.
- Remove the Hard Drive.

To reassemble your device, follow these instructions in reverse order.