



Written By: Kristen Gismondi



Page 1 of 3



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Back Cover



- Remove nine 7.5mm Phillips #00 screws from the bottom of the laptop.
- Use an opening tool to remove the bottom half of the case from the laptop.

Step 2 — Network Card



- Use the Phillips #00 screwdriver to remove the single screw holding in the network card.
- Remove the network card from the laptop.

To reassemble your device, follow these instructions in reverse order.