




# Dell Inspiron 13-7373 Speakers Replacement

This guide is a replacement guide to the speakers of a Dell Inspiron 13-7373.

Written By: John Egan



## INTRODUCTION

This guide will assist in replacing the speakers on a Dell Inspiron 13-7373. This is not very difficult and requires very little removal of other parts of the laptop. You will need a screwdriver along with a tool to open the laptop.

### TOOLS:


- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Back Cover



- Remove nine 7.5mm Phillips #00 screws from the bottom of the laptop.
- Use an opening tool to remove the bottom half of the case from the laptop.

## Step 2 — Speakers




- Unplug the connector from the motherboard on the right side of the speaker.

## Step 3



- Uncoil the wire connecting the left and right speaker from around the bottom of the battery.

## Step 4



- Gently lift up on the left speaker and then the right speaker to remove it.

To reassemble your device, follow these instructions in reverse order.