



Dell Inspiron 14 M4010 Battery Replacement

Written By: Terrence15



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

Step 1 — Slide the Lock Latch



⚠ **WARNING:** Before working inside your computer, read the safety information that shipped with your computer. Follow the instructions in [Before You Begin](#).

- Shut down the computer and turn it over.
- Slide the battery lock latch until it clicks into place.

Step 2 — Sliding the Battery



- Slide the battery release latch to the unlock position.

Step 3 — Lift the Battery



- Slide and lift the battery out of the battery bay.

Step 4 — Align the Tabs



- Align the tabs on the **NEW** battery with the slots on the battery bay.

Step 5 — Slide the Battery



- Slide the battery into the battery bay until it clicks into place.