



Dell Inspiron 1440 Battery Replacement

Is your Dell Inspiron 1440 not holding a charge or dying very quickly? If so here is a guide to replace the battery.

Written By: Tyler Lyons



INTRODUCTION

If you need to remove and replace the Dell Inspiron 1440 battery, look at this guide. Because accessing the battery does not require opening the computer, replacing the battery is easy. This process does not require any tools other than the hands.



PARTS:

- Dell Inspiron 1440, 1750 Replacement Battery (312-0940) (1)

Step 1 — Battery



- Flip the laptop over so the manufacturer's label is facing up.

Step 2



- Use one hand to slide the lock to the left.

Step 3



- While holding the lock, push the battery back.

Step 4



- Slide the battery out.

To reassemble your device, follow these instructions in reverse order.