




# Dell Inspiron 1464 Battery Replacement


Written By: Terrence15



## INTRODUCTION

In this guide, we will show you how to remove and replace the Battery.

## Step 1 — Clicking the Latch




**⚠️** **WARNING:** Before working inside your computer, read the safety information that shipped with your computer. Follow the procedures in [Before You Begin](#).

**⚠️** **CAUTION:** To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface.


- Turn the computer over on a clean, flat surface.
- Slide and click the battery release latch.

## Step 2 — Sliding the Battery



- Slide the battery out of the battery bay.

## Step 3 — Sliding the Battery



- Slide the **NEW** battery into the battery bay, then push to click the battery into place.