




# Dell Inspiron 14R Battery Replacement

Written By: Terrence15



## INTRODUCTION


In this guide, we will be showing you how to remove and replace the Battery.



## PARTS:

- [Dell Inspiron N3010, N4010, N5010 Replacement Laptop Battery \(1\)](#)

## Step 1 — Turn Over the Computer




**⚠️** **WARNING:** Before working inside your computer, read the safety information that shipped with your computer. Follow the instructions in ["Before You Begin"](#).

**⚠️** **CAUTION:** To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface (such as a connector on your computer).


- Shut down the computer and turn it over.

## Step 2 — Sliding the Battery Latch




- Slide the battery release latch to the unlock position.

## Step 3 — Sliding the Battery




- Slide and lift the battery out of the battery bay.

## Step 4 — Sliding the Battery



- Slide the **NEW** battery into the battery bay until it clicks into place.

## Step 5 — Sliding the Battery Latch



- Slide the battery lock latch to the lock position.