# Dell Inspiron 14z 1470 Battery Replacement

This guide will show how to replace the battery in a Dell Inspiron 14z 1470.

Written By: Terrence15

INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery in a Dell Inspiron 14z 1470.

## Step 1 — Turn the Computer Over

⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer. Follow the procedures in [Before You Begin.](#)

⚠ CAUTION: To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface.

- Turn the computer upside down on a clean, flat surface.

Step 2 — Sliding the Latch

- Slide and click the battery release latch.

This document was generated on 2019-11-27 06:55:06 PM (MST).

© iFixit — CC BY-NC-SA | www.iFixit.com | Page 3 of 4

Step 3 — Sliding the Battery

- Slide the battery out of the battery bay.

Step 4 — Sliding the Battery

- Slide the **NEW** battery into the battery bay until it clicks into place.

This document was generated on 2019-11-27 06:55:06 PM (MST).