




# Dell Inspiron 15 7579 2-in-1 Battery Replacement

Written By: Terrence15




## INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

### TOOLS:

- Phillips #0 Screwdriver (1)


## Step 1 — Disconnect the Battery Cable



**⚠️ WARNING:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before Working Inside Your Computer](#). After working inside your computer, follow the instructions in [After Working Inside Your Computer](#).


- Disconnect the battery cable from the system board.

## Step 2 — Remove the Screws



- Remove the screws that secure the battery to the palm-rest assembly.

## Step 3 — Lifting the Battery




- Lift the battery along with the battery cable off the palm-rest assembly.

## Step 4 — Grounding the System Board




- Press and hold the power button for 5 seconds to ground the system board.

## Step 5 — Align the Screw Holes




- Align the screw holes on the **NEW** battery with the screw holes on the palm-rest assembly.

## Step 6 — Replace the Screws



- Replace the screws that secure the battery to the palm-rest assembly.

## Step 7 — Connecting the Battery Cable



- Connect the battery cable to the system board.