




# Dell Inspiron 15 Gaming 7577 Display Assembly Replacement

Written By: Terrence15




## INTRODUCTION

In this guide, we will be showing you how to remove and replace the Display Assembly.

### TOOLS:

- Phillips #0 Screwdriver (1)


## Step 1 — Remove the Screws



**WARNING:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before Working Inside Your Computer](#). After working inside your computer, follow the instructions in [After Working Inside Your Computer](#).

- Remove the two screws (M2.5x5) that secure the display hinges to the palm-rest assembly.

## Step 2 — Open the Display Hinges



- Open the display hinges at an angle of 90 degrees.

## Step 3 — Lifting the Palm-Rest Assembly




- Lift the palm-rest assembly off the display assembly.

## Step 4 — Display Assembly




- After performing the above steps, you will be left with the display assembly.

## Step 5 — Placing the Palm Rest




- Place the palm-rest assembly on the display assembly.

## Step 6 — Close the Display Hinges



- Close the display hinges at an angle of 90 degrees.

## Step 7 — Replace the Screws



- Replace the two screws (M2.5x5) that secure the display hinges to the palm-rest assembly.