




# Dell Inspiron 15-3521 Optical Disc Drive Replacement

Written By: Andrew Dippre



 **TOOLS:**

- Phillips #0 Screwdriver (1)

**PARTS:**

- Optical Drive (1)

## Step 1 — Removing the Battery



! We are removing the battery to avoid the possibility of an electrical discharge when working with this system.

- Flip the laptop over.
- Slide the latches toward the outside of the laptop to unlock the battery.
- Lift the battery out of the laptop.

## Step 2 — Removing the Optical Drive



- Using a Phillips head screwdriver, remove the optical drive screw.
- Remove the optical drive.

To reassemble your device, follow these instructions in reverse order.