



# Dell Inspiron 15-7547 Bottom Cover Replacement

Replace your cover if it is damaged, or remove to get to the parts inside.

Written By: Claro



## INTRODUCTION

This guide shows how to unscrew and remove the bottom cover of your Dell Inspiron 15-7547, allowing access to the underside of the computer where all the important components are.

### TOOLS:

- [Spudger](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Bottom Cover



- Close the display and flip the laptop on its back.
- Loosen the ten 5.0 mm-long Phillips #0 screws.
- The four screws marked with orange will remain captive to the cover.

## Step 2



- Pry the cover open with a plastic spudger and remove it.

To reassemble your device, follow these instructions in reverse order.