



Dell Inspiron 15-7569 Back Cover Replacement

This guide will teach you how to remove your back cover.

Written By: Matthew Clements



INTRODUCTION

Removing your back cover is required for any other repairs and this guide will show you how to remove it.

TOOLS:

- Metal Spudger (1)
- Phillips #0 Screwdriver (1)

Step 1 — Back Cover



- Remove the (10) P58F black screws on the back cover using the Phillips #0 screwdriver.
- After removing the screws, remove the back cover using a plastic or metal spudger.

To reassemble your device, follow these instructions in reverse order.