




Dell Inspiron 15z 1570 Battery Replacement

Written By: Terrence15




INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

TOOLS:

- Anti-Static Wrist Strap (1)

Step 1 — Sliding the Latch




⚠️ **WARNING:** Before working inside your computer, read the safety information that shipped with your computer. Follow the procedures in [Before You Begin](#).

⚠️ **CAUTION:** To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface.


- Turn the computer upside down on a clean, flat surface.
- Slide and click the battery release latch.

Step 2 — Sliding the Battery



- Slide the battery out of the battery bay.

Step 3 — Sliding the Battery



- Slide the battery into the battery bay until it clicks into place.