



Dell Inspiron 17-3721 Battery Replacement

This guide will be showing how to replace a broken or dead battery on the Dell Inspiron 17-3721.

No tools are required for this replacement.


Written By: Zachary Taylor



INTRODUCTION

Over time, laptop batteries will stop holding their charge and eventually die out. This guide will show how to remove and replace the battery of the device.

Step 1 — Battery



⚠ Be sure the laptop is shut off and unplugged from the wall outlet.

- Slide each latch out to unlock the battery.

Step 2



- Use your thumb to lift the battery out of its slot by lifting the bottom edge of the battery.

To reassemble your device, follow these instructions in reverse order.