



# Dell Inspiron 17-3721 Keyboard Replacement

This guide will be showing how to replace a broken or malfunctioning keyboard on the Dell Inspiron 17-3721.

Written By: Kevin Prairie




## INTRODUCTION

Malfunctioning keys or a completely broken keyboard can render a laptop useless to the user. This guide will show the steps to replace the keyboard of this device.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Metal Spudger](#) (1)


## Step 1 — Keyboard



- Use a plastic opening tool or a metal spudger to pry out the tabs on top of the keyboard.
- After prying the tabs up, carefully pull the keyboard out of the laptop.

**⚠** Use caution when prying the tabs up or lifting the keyboard up, as the plastic material and the strip on the keyboard can easily break.

## Step 2



- Once the keyboard is lifted, locate the release tab.
- Using a plastic opening tool or your finger, lift the tab so that it opens .
- Once the tab is open, the strip on the keyboard can be removed.

To reassemble your device, follow these instructions in reverse order.