



# Dell Inspiron 1721 Battery Replacement

This guide demonstrates how to easily remove and replace the battery from the Dell Inspiron 1721.

Written By: Scott Nadeau




## INTRODUCTION

The battery on a Dell Inspiron 1721 is a quick and easy replacement. The battery may need to be replaced if the battery life has diminished or if a person needs to perform any replacements or removals of other parts.

Before removing the battery, make sure the device is completely turned off.

## Step 1 — Battery



- Slide tabs outward to undo the locks.
- Grab and pull the battery away from the device to remove.

To reassemble your device, follow these instructions in reverse order.