




Dell Inspiron 700m Hinge Cover Replacement


Written By: irlanda



 **TOOLS:**

- [Spudger \(1\)](#)


Step 1 — Removing battery



- Remove the battery.


 Make sure your computer is turned off and unplugged.

Step 2 — Open display




- Open the display 180 degrees.

Step 3 — Removing Display



- Use a plastic flat screwdriver to slide the hinge caps away from the computer.

Step 4 — Removing Display



- Detach the two display latches on the back of the computer.

Step 5 — Removing Display



- Use plastic flat screwdriver to carefully pry up the latches on either side of the hinge cover

Step 6 — Removing Display



- Carefully, lift the hinge cover from the main unit and remove it from the main unit.

To reassemble your device, follow these instructions in reverse order.