



Dell Inspiron 910 Battery Replacement

This guide will show you how to replace the battery from the Dell Inspiron 910.


Written By: Kyle Beekman



INTRODUCTION

Before starting the procedures make sure the laptop is turned off and unplugged from the charger.

Step 1 — Remove Battery



- Locate the release tabs located on either side of the battery, on the bottom of the laptop.
- Push the release tabs toward the center of the device.
- Remove the battery.

Your computer may now be turned back on.