



Dell Inspiron 910 Solid-State Drive (SSD) Replacement

Remove and Install SSD.

Written By: Devyn Johnson



1	screw (2)	2	solid-state drive
---	-----------	---	-------------------

 **TOOLS:**

- [Pro Tech Toolkit \(1\)](#)

Step 1 — Remove screws from SSD



1	screw (2)	2	solid-state drive
---	-----------	---	-------------------

 "CAUTION" If you remove the solid-state drive from the computer when the drive is hot, do not touch the solid-state drive

- Remove the two screws that secure the solid-state drive.
- Lift the solid-state drive out of its system board connector.

Step 2 — Insert New Solid-state Drive



- Insert the solid-state drive into the slot at a 45-degree angle.
- Press the solid-state drive down and replace the two screws that secure the drive.
- Replace the module cover
- Slide the battery into the battery bay, until it clicks into place and slide the battery-lock latch towards the lock position.

Step 3 — Replacing all screws



- Make sure to replace all screws and ensure that there are no stray bolts.

To reassemble your device, follow these instructions in reverse order.