




Dell Inspiron 910 Touchpad Buttons Replacement

Use this guide to replace the trackpad buttons on your Dell Inspiron 910

Written By: Kyle Beekman



INTRODUCTION

This guide will teach you how to remove the buttons below the track pad from the laptop device.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Remove Battery



- Locate the release tabs located on either side of the battery, on the bottom of the laptop.
- Push the release tabs toward the center of the device.
- Remove the battery.

Step 2 — Keyboard



- Remove the two countersunk keyboard screws using the Phillips #00 screwdriver


ⓘ Battery removal is not necessary for keyboard removal.

Step 3



- Lift up the keyboard using your fingers or a plastic opening tool
- ⚠ Do not tear the ribbon cable hidden behind the keyboard
- Disconnect the cable by sliding the connector ears outward


Step 4 — Touchpad Buttons



- Remove the seven Phillips #00 screws that hold the metal component to the frame
- Detach the two ribbon cables on either side of the silver panel
- ⚠ Be careful to not tear the ribbon cables hidden behind the panel
- Gently lift the silver panel from the laptop using the plastic opening tool
- Set the laptop aside


ⓘ depending on your model, there could still be some hidden screws on the bottom of the case of the mini that hold the palm-rest in place

Step 5



- Flip the silver panel over
- Remove the four screws that connect the buttons to the panel using the Phillips #00 Screwdriver

Step 6



- Remove the covers from the panel
- Remove the buttons from the panel
- Release the mouse button by flipping the center connector tab up

To reassemble your device, follow these instructions in reverse order.