




Dell Inspiron N4010 Battery Replacement

This guide will show you how to remove and replace the Battery in your Inspiron 14R. This will serve as a prerequisite to almost every guide.


Written By: Jonathan Sellier



INTRODUCTION

Removing the battery is usually the first step in every hardware replacement guide. It is also the easiest guide with minimal risk to the user performing the removal and replacement. This guide requires no tools and no prior experience with computer repair.

Step 1 — Battery




- ⚠ Make sure the laptop is not plugged into any wall outlets or the charger
- Unlock the battery by sliding the right-hand switch to the right.

Step 2



- While holding the left-hand switch to the left position, pull the battery away from the laptop.

Step 3



- The battery is now fully removed and the laptop will not power on without it.

To reassemble your device, follow these instructions in reverse order.