



Dell Latitude D610 Battery Replacement

Replacement of the battery for a Dell Latitude D610

Written By: Cinthya



INTRODUCTION

Replacing a defective battery is pretty easy and will increase the time your computer will last after charging.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Battery



- Remove the 3.9 mm Phillips #1 screw from the battery compartment.

Step 2



- Locate the laptop battery release button lock
- Push the battery release in the direction of the arrow, and pull upward.

Step 3



- Remove the battery from its compartment.

To reassemble your device, follow these instructions in reverse order.