



Dell Latitude D830 Battery Replacement

This guide demonstrates how to replace the Battery on the Dell Latitude D830.

Written By: Nick Long




Step 1 — Battery



- Orient the laptop so the opening is facing you.

Step 2



- Flip the laptop over, so the opening is still facing you.

Step 3




- Place finger/ thumb on the slide button, then push the button forward
- This unlocks the battery.

Step 4



- Place finger/thumb under the ledge.

Step 5




- Lift up the ledge, this allows the battery to be removed.

Step 6




- The battery is now removed.

Step 7



- To insert a new battery, orient the battery with the battery opening.

Step 8



- Insert the new battery with the left side being placed in first.
- Press the new battery down until a "click" is heard.

To reassemble your device, follow these instructions in reverse order.