



Dell Latitude E5410 Battery Replacement

Replacement of the battery for the Dell Latitude E5410.

Written By: Megan Perrizo



INTRODUCTION

This guide will show you how to replace the battery.



PARTS:

- [Dell Latitude E5410 battery](#) (1)

Step 1 — Battery Replacement



- Have your Dell Latitude E5410 unit ready face down.

Step 2



- Use your thumb to move the tab to the right that releases the battery, while using your other hand to slide the battery out.
- The battery will come out straight toward you.

Step 3



- Have your replacement battery ready to slide in.

To reassemble your device, follow these instructions in reverse order.