



Dell Latitude E5410 Screen Replacement

This guide will show you how to replace a screen on the Dell Latitude E5410.

Written By: Darby



INTRODUCTION

This guide will show you how to replace a screen on the Dell Latitude E5410.

TOOLS:

- [Mako Driver Kit - 64 Precision Bits \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Spudger \(1\)](#)

Step 1 — Dell Latitude E5410 Screen Replacement



- Have your laptop ready with your screen pulled all the way down parallel to the bottom of the laptop.

Step 2




- Start on the top left or right corner of the screen edge and unscrew the small screws.
- Be sure to remove the rubber placeholders in order to access the screws.

Step 3




- Using a plastic opening tool, pry the bezel away from the screen.

Step 4



- Use the Phillips screwdriver to remove the screws from corners around the screen.

Step 5




- Remove the screws from both sides.
- Once removed, they will release the screen.

Step 6



- Use the spudger to move the sensor aside.

Step 7



- Release the screen by pulling up and out.

To reassemble your device, follow these instructions in reverse order.