# Dell Latitude E6330 Battery Replacement

Guide for replacing a worn out or faulty battery in your Dell Latitude E6330.

Written By: david schudrich

www.iFixit.com

Step 1 — Battery

- Turn off computer

Step 2

- Slide latches out to unlock and remove battery.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-01-14 01:56:44 AM (MST).

www.iFixit.com