



Dell Latitude E6330 Screen Replacement

Use this guide to replace the screen to the Dell Latitude E6330

Written By: Brett Murray



 **TOOLS:**


- [Phillips #00 Screwdriver \(1\)](#)

Step 1 — Battery



- Turn off computer

Step 2




- Slide latches out to unlock and remove battery.

Step 3 — Screen




- Open the laptop and unscrew the 2.5 X 3mm screw in the bottom center of screen

Step 4




- Using a spudger, carefully remove of the exterior black frame/cover of the screen

Step 5



- Using a Philips head screw driver, screw the ten surrounding 2.5 X 3mm screws on the frame of the screen

Step 6



- Detach the yellow LCD inverted from the back of the screen

Step 7



- Carefully pull off the screen itself

To reassemble your device, follow these instructions in reverse order.