




# Dell Latitude E7470 RAM Replacement

Step by step guide to replace the RAM of a Dell Latitude E7470.

Written By: Hyperion



 **TOOLS:**

- Phillips Size 0 Screwdriver (1)
- iFixit Opening Picks set of 6 (1)
- Anti-Static Wrist Strap (1)

 **PARTS:**


- New Item (1)

## Step 1 — Remove cover



- Start by removing the 8 screws circled in red in the photo with the Philips # 0 screwdriver.
- Then, using the iFixit Opening Picks, lift up from the dock connector end. Unclip it gently.

## Step 2 — RAM replacement



- After removing the cover, locate the slots for RAM in the computer. There are 2 of them.

**⚠** Attention, only the DDR4 memory in portable format is compatible with the motherboard of this PC!

To reassemble your device, follow the instructions in reverse order.