




Dell Optiplex 745 Ultra Small Form Factor Side Panel Replacement

Remove the Panel Case


Written By: donnavon



INTRODUCTION

Remove the Panel Cover to access the components of the device.


Step 1 — Side Panel



⚠ Make sure to shut down the computer! you can do this by going to the start menu and clicking shutdown.

⚠ Ensure all cables, speakers and other devices are unplugged and turned off before opening the computer case.

Step 2



- Lay the computer on its side; you will see a blue knob. Turn said knob 90 degrees counter clockwise.

Step 3



- Slide the panel case forward about 1/2 inch while knob is turned.
- Lift panel case off computer.

To reassemble your device, follow these instructions in reverse order.