




Dell Precision 7720 Hard Drive Replacement

Written By: Johnathan Hammond



 **TOOLS:**


- Phillips #0 Screwdriver (1)

Step 1 — Battery Cover




- Slide the release latch towards the unlock icon to release the battery cover [1].
- Slide and lift the battery cover to remove it from the computer [2].

Step 2 — Battery



- Slide the release latch towards from the unlock icon to unlock the battery[1].
- Lift and remove the battery from the computer [2].

Step 3 — Hard Drive



- Remove the M3.0x3.0 screws that secure the hard drive to the computer [1].
- Lift the hard drive latch to release the hard drive [2].
- Slide and lift the hard drive from the computer [3].

To reassemble your device, follow these instructions in reverse order.