



Dell Precision M2800 Memory Module Replacement

Written By: Johnathan Hammond



 **TOOLS:**


- Phillips #0 Screwdriver (1)

Step 1 — Battery



- Slide the release latches to unlock the battery.
- Flip the battery out of the computer.

Step 2 — Base Cover



- Remove the screws that secure the base cover to the computer.
- Lift the base cover and remove it from the computer.

Step 3 — Memory Module



- Pry the securing clips away from the memory module until it pops-up and remove the memory module from its connector on the system board.

To reassemble your device, follow these instructions in reverse order.