Dell Precision M3800 Back Cover Replacement

This is a guide on how to remove the back cover of the Dell Precision M3800 so that you can replace/repair any components inside.

Written By: Brianna Hitchcock

This document was generated on 2020-01-18 04:38:09 PM (MST).

www.iFixit.com

INTRODUCTION

The first step in any kind of replacement is to remove the back cover on the laptop.

Before beginning, be sure to power down the laptop and unplug it from any external power source(s). This guide will show you how to remove the back cover in your laptop.

🔧 TOOLS:

- T5 Torx Screwdriver (1)
- iFixit Opening Tools (1)

This document was generated on 2020-01-18 04:38:09 PM (MST).

www.iFixit.com

Step 1 — Back Cover

- Use a T5 Torx screwdriver to unscrew the ten 3mm screws on the laptop back cover and then remove the cover.

- (i) iFixit's magnetic project mat is great for keeping the screws in one place.

- If the back cover is hard to remove, use a plastic opening tool to remove the back cover.

To reassemble your device, follow these instructions in reverse order.