



# Dell Precision M3800 Base Cover Replacement

Written By: Johnathan Hammond



 **TOOLS:**

- T5 Torx Screwdriver (1)

## Step 1 — Base Cover



- Turn the system badge fap over and place it on the base cover.
- Remove the screws that secure the base cover to the computer. Release and remove the base cover from the computer.

***i*** NOTE: To remove the screws from the base cover, use a T5 Torx screwdriver.

- Lift up and remove the base cover from the computer.

To reassemble your device, follow these instructions in reverse order.