




# Dell Precision M3800 Battery Replacement

Written By: Johnathan Hammond



 **TOOLS:**

- [T5 Torx Screwdriver \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)

## Step 1 — Base Cover




- Turn the system badge fap over and place it on the base cover.
- Remove the screws that secure the base cover to the computer. Release and remove the base cover from the computer.

***i*** NOTE: To remove the screws from the base cover, use a T5 Torx screwdriver.

- Lift up and remove the base cover from the computer.

## Step 2 — Battery



- Disconnect the battery cable from the system board [1].
- Remove the screws that secure the battery to the computer.
- Lift the battery off the computer [2].

To reassemble your device, follow these instructions in reverse order.