



Dell Precision M4500 Memory Module Replacement

Written By: Johnathan Hammond



 **TOOLS:**

- Phillips #0 Screwdriver (1)

Step 1 — Battery



- Slide the battery release latches to the unlock position.
- Slide and remove the battery from the computer

Step 2 — Base Cover



- Loosen the captive screw that secures the access panel to the base of the computer.
- Slide the access panel towards the front of the computer.
- Lift the access panel up and away from the computer.

Step 3 — Memory Module



- Carefully spread apart the securing clips on each end of the memory module connector until the memory module pops up.
- Remove the memory module from the connector.

To reassemble your device, follow these instructions in reverse order.